UPDATE

System requirements for USB storage media:

max. 32GB, FAT32 formatting, no external hard drive or partitions.
Also the update file must be located in the root directory respectively in the "FRONIUS" folder.

Procedure:

1. The USB menu should open up automatically after connecting the USB Stick to the charger. If this
    is not the case:

Press menu button for 5 seconds

2. Go to the menu item "USB" by using the up/down buttons and confirm with the stop/start button.
    Note: Only if there is an update file on the USB stick, the menu item "Update" is shown and can be
    selected.

3. The Update starts automatically after it has been selected and should not been interrupted, e.g. by
    cutting off the AC supply.

4. "Update successful" is shown on the display. Confirm it with the Stop/Start button.
    Then the device jumps back to the main menu again.

5. Finally, choose and confirm the menu item "safely remove" within the USB menu. Then the USB
    stick can be safely removed from the charger.